




Keypad & Remote Operation #1 - Air Massage Air Bath



ON/OFF

1st Press:

Blower starts.
Light on.

2nd Press:

Blower stops.
Light off.



INCREASE

Press & hold

to increase.
Release at
desired
speed.

Starts at
30% Speed.



DECREASE

Press & hold

to decrease.
Release at
desired
speed.



SPA MODE

1st Press: WAVE

Speed Varies Max. to Min.
Light on.

2nd Press: PULSE

Speed Varies Min. to Max.
Light Flashes

3rd Press: STEADY

Speed Max. to adjust use "decrease".
Light off - Spa Mode off.



Notes:

1. Blower Stops after 20 Minutes
2. Seven (7) Minutes after the water has drained from the tub, the blower will automatically turn on for 1 minute to purge water from the top of the air jets.