




# Keypad #4 Operation - Air Massage Elite w/Chromatherapy



## SPA MODE ON/OFF

### 1st Press:

Spa Mode On  
Use arrows to  
cycle through  
modes:

1. Energentic
2. Relaxing
3. Deep Tissue

### 2nd Press:

Spa Mode Off  
Press and Hold



## AIR BATH ON/OFF

### 1st Press:

Blower starts.  
Use arrows to  
adjust speed.

Starts 30%

### 2nd Press:

Blower stops.



## INCREASE

**Press & hold**  
to increase.

Release at  
desired  
speed/mode.



## DECREASE

**Press & hold**  
to decrease.

Release at  
desired  
speed/mode.



## PULSATION MODE

### 1st Press: WAVE

Speed gradually  
varies Min. to Max.

### 2nd Press: PULSE

Speed quickly varies  
Min. to Max.

### 3rd Press: MAX SPEED

### 4th Press: PULSE

Returns to Pulsation  
Mode



## LIGHTS ON/OFF

### 1st Press: BASIC

Start - white. Use  
arrows to cycle colors.

### 2nd Press: RAINBOW

Starts slow, use arrows  
to adjust speed.

### 3rd Press: SLOW

Aqua blue/green cycle,  
use arrows to adjust speed.

**Press & Hold to turn off.**

## Notes:

1. Air Bath blower Stops after 20 Minutes.
3. Air Bath - Seven (7) Minutes after the water has drained from the tub, the blower will automatically turn on for 1 minute to purge water from the top of the air jets.