




Keypad #6 Operation - Air Massage Elite w/Chromatherapy



SPA MODE ON/OFF

1st Press:

Spa Mode On
Use arrows to
cycle through
modes:

1. Energenic
2. Relaxing
3. Deep Tissue

2nd Press:

Spa Mode Off



AIR BATH ON/OFF

1st Press:

Blower starts.
Use arrows to
adjust speed.

Starts 30%

2nd Press:

Blower stops.



INCREASE

Press & hold
to increase.



DECREASE

Press & hold
to decrease.

Release each
at desired
speed/mode.



PULSATION MODE

1st Press: WAVE

Speed gradually
varies Min. to Max.

2nd Press: PULSE

Speed quickly varies
Min. to Max.

3rd Press: MAX SPEED

4th Press: PULSE

Returns to Pulsation
Mode



WHIRLPOOL PUMP ON/OFF

Large Point Jets

1st Press:

Pump turns on.
Use Air Volume
control to adjust
pressure.

2nd Press:

Pump turns off.



LIGHTS ON/OFF

1st Press: BASIC

Start - white. Use
arrows to cycle colors.

2nd Press: RAINBOW

Starts slow, use arrows
to adjust speed.

3rd Press: SLOW

Aqua blue/green cycle,
use arrows to adjust
speed.

Press & Hold to turn off.

Notes:

1. Air Bath blower Stops after 20 Minutes.
3. Air Bath - Seven (7) Minutes after the water has drained from the tub, the blower will automatically turn on for 1 minute to purge water from the top of the air jets.